


ACOUSTICAL A.M. TUNER



WAVECHANGE SWITCH S1 SHOWN IN MW POSITION SELECTIVITY SWITCH S2 W = WIDE T = TUNE ALL RESISTORS ARE I_2 WATT UNLESS OTHERWISE SHOWN